

NOTICE LIGHTING MODULE: BulM S (ref LAM200-S-E12) Read carefully before use and keep IMPORTANT

- . Only Lairial components must be used
- . Before use: if the end of the lamp jewel (spring) is pushed in, gently stretch it to reshape it
- . Only E12 bulbs (diameter 4 in max), 40 W max must be used
- . Do not leave Volupte near a flame
- . If the cable is damaged, it must be replaced exclusively by Lairial

CONNECTING /DISCONNECTING

CAUTION: Before connecting the modules, disconnect BulM from the socket or switch off the power to the electrical panel (pendant)

A-CONNECT



1- Prepare the modules (lighting and wire)



2- Insert the male connector into the female connector until you hear a "click"



3- Move the two springs together



4- Insert the wire module holder into the spring of BulM (Blistering at the tip)



5- Hold the BulM spring with your hand and turn the other part of the spring clockwise.
Pull lightly to check for

B-DISCONNECT

- 1- Hold the BulM spring with your hand and unscrew the spring from the connector module counterclockwise. **IMPORTANT:** do not disengage the springs by pulling
- 2- Disconnect by pulling lightly

IMPORTANT: the spring has only aesthetic function. Do not pull on the turns, it will distort it and harm the aesthetics of the object

INSTALL / CHANGE BULB

IMPORTANT: Do not touch the bare hand glass

- 1- Unplug BulM from the socket or switch off the power on the electrical panel (pendant)
- 2- Disconnect BulM (see connection / disconnection + up) and place it
- 3- Remove several slats from the disc to have access to the bulb inside
- 4- Let the lamp cool
- 5- Hold the socket with one hand, and with the other hand screw / unscrew the bulb
- 6- Replace the slats in the notches of the disc by positioning them perpendicular to the disc

USE AS A PENDANT (with the wire modules ref LAA110-US / 210-US)

Depending on the wire module, the connection is made to the ceiling or via a plug. For ambient lighting, a luminous sculpture in space.

USE AS A TABLE LAMP or FLOOR LAMP (with wire module ref LAA100-US)



You can use BulM in both directions:

- horizontally (luminous presence)
- upright, "way up light" bulb up. In this case, gently bend the cable to the output of the disc and position it between 2 slats.

CLEANING

The shape of BulM prevents the dust from settling. However, if you want to clean it:

- 1- Disconnect BulM from the power socket or turn off the power on the electrical panel (pendant)
- 2- Disconnect BulM from the connection module (see connect / disconnect) and place it
- 3- Remove the first slat from the disc, hold it with one hand and gently remove the dust with a soft cloth (NO WATER, NO CHEMICAL OR DETERGENT). Replace the slat in the notch of the disc by positioning it perpendicular to the disc
- 4- Repeat with the other slats
- 5- Reconnect BulM to the connection module (see connect / disconnect) and reconnect the power.

NOTES & ADVICE

- . Small cuts and cracks may occur. These evolutions, which do not question the structure of the lamp, show that wood is a living material and that your luminaire is unique
- . Differences in color and veining may occur because wood is a living material and therefore unique

Lairial has chosen to leave natural wood outside without treatment.

- . Its color will evolve slightly over time and strengthen its living character
- . We recommend not to apply any paint or varnish that could stiffen the wood which could then no longer twist